

255 Welter Drive
Monticello, IA 52310



Phone: (877) 465-4344
Fax: (877) 465-4042
www.oakstreetmfg.com

METAL FRAME BARSTOOL ASSEMBLY INSTRUCTIONS

YOU'LL NEED:

- A PHILLIPS HEAD ELECTRIC DRILL
- 10 MM WRENCH



1. Place metal seat on metal frame and attach 4 bolts with 10mm nuts using Phillips head and 10mm wrench.
2. Cover working surface with corrugated or cloth to protect seat.
3. Place wooden seat face down on protected area.
4. Turn barstool upside down on wooden seat.
5. Center seat on frame.
6. Use Phillips head to attach 5 screws to wooden seat.
7. Carefully flip barstool over.