

Pacific Refrigerator offers two styles of Replacement Walk-In Doors:

❖ Flush Door

- The pull (exterior) leaf of the door is inset and sits flush with the exterior wall of the walk-in.
- A flush door is appropriate for situations where the existing door **frame** is in serviceable condition (straight, free of dents and dings or any loose parts or missing trim/metal)
- Use the “Flush Walk-In Door Order Form” to order a replacement flush door. This sheet contains fields to specify the existing door frame profile dimensions. The door will be manufactured with the proper dimensions and clearances to fit the existing frame. The form also contains fields to specify the dimensions of the existing door; these dimensions are used as a cross-check.



❖ Offset Door

- The pull (exterior) leaf of the door has a “flange” that overlays the exterior face of the walk-in wall.
- An offset door is appropriate for situations where the existing door frame is square and does not have a typical recessed flush-style jamb stop.
- Use the “Offset Door Order Form” to order a replacement offset door. The only dimensions needed for an offset door are the clear (unobstructed) door frame opening, and the thickness of the adjacent wall. Pacific will manufacture the door with the proper dimensions and clearances.

