

LOADING DISPENSER

- Open dispenser via pushing the front and pulling the face plate up
- Properly load dispenser with interfold napkins



INSERTING ADVERTISEMENT

- Open dispenser via pushing the front and pulling the face plate up
- Slide ad insert into the side pocket
Fits: 6.5" w x 4.25" h advertisements

