

REVERSIBLE SHEETERS Parts Breakdown

BMCRS01 BMCRS02 BMFRS01 BMFRS02 BMFRS03




6.PARTS CATALOG


6-1 PARTS CATALOG

FLOOR TYPE

NO.	MAME	NO.	MAME
1	key	2	Shaft sprocket
3	Deep groove ball bearing 600-1ZZ	4	Bearing block
5	Shaft sprocket	6	Chain
7	Chain	8	Pin bearing FC-20
9	Deep groove ball bearing 6U03ZZ	10	C. Retainer ring S-17
11	Stay	12	Chain
13	Shaft sprocket	14	Chain
15	Chain	16	Spacers
17	Washer, Oat	18	Bolt
19	Support bracket	20	Rear panel
21	Rear casing	22	Deep groove ball bearing 6205ZZ
23	C. Retainer ring R-52	24	Chain
25	C. Retainer ring S-70	26	Expansion spring
27	Connecting board	28	Lever ring
29	Chain	30	Chain
31	Deep groove ball bearing 6205ZZ	32	Chain
33	Motor	34	Conveyor belt
35	Bolt, adjustable	36	Left support bracket
37	,	38	Extension catch pan
NO.	Right support bracket	NO.	MAME
NO. 39	MAME Shaft, driven	40	C. Retainer ring S-17
41	,	42	Roller
	Deep groove ball bearing 6203ZZ		
43	Rase	44	Connecting rod
45	Left support bracket Base	46 48	Right support bracket
47 49		50	Bearing block Thrust ball bearing 51203
51	Deep groove ball bearing 6003ZZ Shall, roll	52	
53		54	Bearing block Nut
55	Axle, supporting	56	
	Seat, sliding		Deep groove ball bearing 6205ZZ
57	Up roller	58	Bolt, adjustable
59	Lever, dead	60	Link mass
61	Torsional spring	62	Bar, fulcrum
63	Strickle sweep	64	Bar, fulcrum
65	Front casing	66	Roller head housing
67	Stop pin	68	Safety guard
69	Deep groove ball bearing 6205ZZ	70	Down roller
71	Strickle sweep	72	Bolt, support
73	Bolt, anchor block	74	Set screw
75	Expansion spring	76	Rings
77	Trigger	78	Microswitch
79	Bolt, hexagon head	80	Washer, spring
NO.	MAME	NO.	MAME
81	Washer, flat	82	Trigger
83	Microswitch	84	Bolt
85	Compression spring	86	Ball
87	Fixed support	88	Locating mass

89	Movement control lever	90	Bolt, shaft
91	C. Retainer ring S-25	92	Connecting board
93	Graduated scale	94	Finger
95	Handle base	96	Front panel
97	Washer, flat	98	Handle
99	Spacers	100	Spacers
101	Bolt cover	102	Fin
103	Compression spring	104	Trigger, locking pin
105	Locking mass	106	Rail rest
107	Bolt, cheese head	108	










Figure 3 Floor Model





BENCH TYPE

BEIN	СНТҮРЕ		
NO.	MAME	NO.	MAME
1	key	2	Shaft sprocket
3	Deep groove ball bearing 6004ZZ	4	Bearing block
5	Shaft sprocket	6	Cham
7	Chain	8	Pin bearing FC-20
9	Deep groove ball bearing 6003ZZ	10	C. Retainer ring S-17
11	Stay	12	Chain
13	Shaft sprocket	14	Chain
15	Chain	16	Spacers
17	Washer, flat	18	Bolt
19	Support bracket	20	Rear panel
21	Rear casing	22	Deep groove ball bearing 6205ZZ
23	C. Retainer ring R-52	24	Chain
25	C. Retainer ring S-70	26	Expansion spring
27	Connecting board Chain	28	Lever ring
29		30	Chain
31	Deep groove ball bearing 6205ZZ	32	Chain
33	Motor	34	Conveyor belt
35	Bolt, adjustable	36 38	Left support bracket
37 NO.	Right support bracket MAME	NO.	Extension catch pan MAME
NO. 39	Shalt, driven	40	C. Retainer ring S-17
41	Deep groove ball bearing 6203ZZ	42	Roller
43	Base	44	Connecting rod
45	Left support bracket	46	Right support bracket
47	Base	48	Bearing block
49	Deep groove ball bearing 6003ZZ	50	Thrust ball bearing 51203
51	Shaft, roll	52	Bearing block
53	Axle, supporting	54	Nut
55	Seat, sliding	56	Deep groove ball bearing 6205ZZ
57	Up roller	58	Bolt, adjustable
59	Lever, dead	60	Link mass
61	Torsional spring	62	Bar, fulcrum
63	Strickle sweep	64	Bar, fulcrum
65	Front casing	66	Roller head housing
67	Stop pin	68	Safety guard
69	Deep groove ball bearing 6205ZZ	70	Down roller
71	Strickle sweep	72	Bolt, support
73	Bolt, anchor block	74	Set screw
75	Expansion spring	76	Rings
77	Trigger	78	Microswitch
79		80	
<u> </u>	Microswitch	84	Boll
83 85	Compression spring	86	Ball
85 87	Compression spring	88	Locating mass
07		00	Locating mass
89	Movement eontrol lever	90	Boll, shaft
91	C. Retainer ring S-25	92	Connecting board
93	Graduated scale	94	Finger
95	Handle base	96	Front panel
97	Washer, (lal	98	Handle
99	Spacers	100	Spacers
101	Bolt cover	102	Pin
103	Compression spring	104	Trigger, locking pin
105	Locking mass	106	Rail rest
107	Bolt, cheese head	108	Nut
109	Deep groove ball bearing 6003ZZ	110	Idler wheel
111	Fixed base	112	Fixed board
113	Locating mass	114	
	=		









Figure 6 Countertop Model













6-2.CHAIN ALLOCATION PLAN BENCH TYPE

Front TOP: Rear Chain Allocation

BOTTOM: Front Chain Allocation





Warranty



- One year Parts and Labor limited warranty.
- Warranty begins at date of installation, delays of installation and extended warranty must be approved.
- All equipment must be properly installed and connected by qualified professionals if not a standard Plug 'N Go* operation.
- All equipment must be used within tolerance limits of machine.
- Any abuse of equipment or improper use of machine will void the warranty.
- Accessories or attachments have 90 day warranty to be repaired or replaced.
- Repairs include Parts and Labor only, excluded are the following:
 - Electrical components such as fuses, bulbs, elements switches are not covered by this warranty.
 - Overtime labor rates.
 - Expedited freight for parts.
 - Travel charges.
- All defective parts must be returned to BakeMax® for credit.
- BakeMax® is not responsible for production downtime or product losses.
- Repairs must be pre-authorized by BakeMax® prior to work commencing.
- o Emergency service 24/7 at 1-800-565-2253

SPECIAL TERMS & CONDITIONS

- BakeMax® reserves the right to make improvements or equipment specification changes without prior notice.
- Set up and installation is client's responsibility.
- Failure to follow all instructions in equipment manual, properly install, maintain equipment, follow capacity charts, or electrical information may void warranty.

BakeMax®

PO Box 23083, Moncton NB, E1A 6S8 Toll Free: 1-800-565-BAKE

Telephone: 1-506-858-8990 Fax: 1-506-859-6929 *Plug 'N Go operation requires machine be properly connected to proper wall outlet.

Think Quality, Value, Service.....Think

BEKAMON

Toll Free: 1-800-565-BAKE Web Site: www.bakemax.com E-mail: sales@bakemax.com