
INSTRUCTIONS FOR REPLACEMENT PANELS ON THE MAXIMIZERTM PORTABLE BAR

Tools Required: Phillips head screw driver, Flat head screw driver or flat edge tool, Clamp, Drill

- 1. Set brakes on wheels (operator side). See diagram A.
- 2. Remove bar top. To remove bar top, unscrew the four screws that are located under outer lip of bar. See diagram A.
- 3. Remove 2 front bar stantions. To remove stantions, unscrew 2 screws for each stantion that are located on the right-hand and left-hand inside part of bar. See Diagram B.
- 4. Pop open screw caps located on front panel and each side panel using flat screwdriver or flat edge tool. Remove screws that are housed in the screw caps.
- 5. Remove all panels.
- 6. Place corresponding panel that was removed (front side facing up) over replacement panel (front side facing up). Make sure panels edges line up exactly, and then clamp together.
- 7. Using the removed panel as a template, drill out holes where existing holes were located. Repeat drilling of holes for each panel.
- 8. Reassemble panels by placing corresponding replacement panel on each side and front of bar unit.
- 9. Replace screws in each screw cap, tighten and snap cap closed.
- 10. Replace each stantion and tighten with screws.
- 11. Replace bar top and secure with four screws.







European Distribution Center: Edisonstraat 84, P.O. Box 110 6900 AC Zevenaar, The Netherlands Tel +31/(0)316-596550 • Telex 45642 FAX +31/(0)316-340168 #104803780

