Assembly Instructions: **Service Cart**

PRODUCT NUMBER: UC4018 & UC4525

Parts List:

- 4 Legs, 4 Corners, 2 Shelves
- 2 Fixed Casters, 2 Swivel Casters, 1 Handle
- 1 Hardware Packet Containing 12 Screws, 16 Bolts,
- 16 Lock Washers, 16 Nuts (15mm)

Tools Needed:

Phillips Screwdriver, Mallet, Wrench

Steps:









Use 4 bolts, lock washers and nuts to secure legs and casters to frame





Use 3 screws to secure each leg to frame



Parts Replacement

