



FRYER BASKET REFERENCE CHART



AMERICAN RANGE

FRYER MODEL	TWIN Front Hook
AF45	225-1060

ANETS

FRYER MODEL	TWIN Front Hook	FULL Front Hook
14	225-1035	225-1003
14B	225-1035	
14D	225-1035	
14E	225-1035	225-1003
14G	225-1035	
14GS	225-1035	
14UT22	225-1035	225-1003
14X1AA	225-1035	
14X1B	225-1035	
14X1D	225-1035	225-1003
14X1DG	225-1035	225-1003
14X1E	225-1035	225-1003
14X1EG	225-1035	225-1003
18D	225-1042	
18E	225-1042	
18EG	225-1042	
18X1	225-1002	225-1053*
18X1AA	225-1002	
18X1B	225-1002	
18X1D	225-1002	225-1053*
18X1E	225-1002	225-1053*
18X1EG		225-1053*
20D	225-1042	
20E	225-1042	
20EG	225-1042	
DI-11	225-1035	225-1003
DI-17	225-1035	225-1003
DI-22	225-1035	225-1003
E11	225-1035	225-1003
E11AA	225-1035	
E11D	225-1035	
E15	225-1035	225-1003
E15AA	225-1035	
E15B	225-1035	
E15D	225-1035	
E17	225-1035	225-1003
E17AA	225-1035	
E17D	225-1035	
E22	225-1035	225-1003
E22AA	225-1035	
E22D	225-1035	
EC11	225-1035	
EC15	225-1035	225-1003

ANETS (continued)

FRYER MODEL	TWIN Front Hook	FULL Front Hook
EC17	225-1035	
EC22	225-1035	225-1003
FGS14-6	225-1035	225-1003
FGS14-6A	225-1035	
FGS14-6B	225-1035	
MX14AA	225-1035	225-1003
MX14D	225-1035	225-1003
MX14E	225-1035	225-1003
MX14EG	225-1035	225-1003
SX14AA	225-1035	225-1003
SX14B	225-1035	
SX14D	225-1035	225-1003
SX14E	225-1035	225-1003

CECILWARE®

FRYER MODEL	TWIN Left Hook	TWIN Right Hook	TWIN Front Hook	TWIN Front Hook E-Z Grip® Handle
EF30			225-1060	225-1061
EF40			225-1060	225-1061
EF65			225-1042	
EFS30			225-1060	225-1061
EFS40			225-1060	225-1061
EFS65			225-1042	
EL14	225-1012	225-1013		
EL120	225-1012	225-1013		
EL250	225-1012	225-1013		
EL270	225-1012	225-1013		
ELT500	225-1012	225-1013		
FM28	225-1014	225-1015		
FMP40			225-1060	225-1061
FMP65			225-1042	
FMS40			225-1060	225-1061
FMS54			225-1042	
GF8			225-1011	
GF10	225-1012	225-1013		
GF14			225-1011	
GF16	225-1012	225-1013		
GF28	225-1014	225-1015		

Note: Inspect condition of basket wires before each use.
Immediately replace basket when wires appear
bent, missing, or damaged.

* This basket has an assist handle

DEAN

FRYER MODEL	TWIN Front Hook	TWIN Front Hook E-Z Grip® Handle	FULL Front Hook	TRIPLE Front Hook
11E	225-1062*	225-1063	225-1003	
11G	225-1062*	225-1063	225-1003	
1212G	225-1000	225-1082		
1212GMS	225-1000	225-1082		
1212GTS	225-1000	225-1082		
14E	225-1062*	225-1063	225-1003	
1414E	225-1062*	225-1063		
1414G	225-1062*	225-1063	225-1003	
1414GMS	225-1062*	225-1063		
1414GTS	225-1062*	225-1063		
1818E	225-1002			225-1041**
1818G	225-1002			225-1041**
1818GTS	225-1002			225-1041**
1824G	225-1062*	225-1063	225-1003	
2020E	225-1002			225-1041**
2020GMS	225-1002			225-1041**
2020GTS	225-1002			225-1041**
2424E	225-1062*	225-1063		
2424G	225-1062*	225-1063	225-1003	
32G				225-1041**
32G	225-1002			225-1041
714E	225-1062*	225-1063		
714GMS	225-1062*	225-1063		
714GTS	225-1062*	225-1063		
Decathlon 60	225-1002			
Decathlon 80	225-1002			

FRYMASTER®

FRYER MODEL	TWIN Front Hook	TWIN Front Hook E-Z Grip® Handle	FULL Front Hook	TRIPLE Front Hook
12EF	225-1062*	225-1063	225-1003	
17EF	225-1062*	225-1063	225-1003	
22EF	225-1062*	225-1063	225-1003	
FM35	225-1010	225-1052		
GF14	225-1010	225-1052		
GF40	225-1062*	225-1063	225-1003	
H14	225-1062*	225-1063	225-1003	
H14		168-1510***		
H14-2	225-1062*	225-1063		
H17	225-1062*	225-1063	225-1003	
H17-2	225-1062*	225-1063		
H22	225-1062*	225-1063	225-1003	
H50	225-1062*	225-1063	225-1003	
JCFX	225-1002		225-1053*	
J1C	225-1000	225-1082		
J1X	225-1000	225-1082		
J2X	225-1010	225-1052		
MJ15	225-1000	225-1082		
MJ35	225-1010	225-1052		
MJ35G	225-1010	225-1052		
MJ40	225-1062*	225-1063	225-1003	
MJ41	225-1062*	225-1063	225-1003	
MJ41E	225-1062*	225-1063	225-1003	
MJ42				225-1054
MJ45	225-1062*	225-1063	225-1003	
MJ45E	225-1062*	225-1063	225-1003	
MJCF	225-1002		225-1053†	225-1054
MJCFE	225-1002		225-1053†	225-1054
MJH50	225-1062*	225-1063	225-1003	

GARLAND®

FRYER MODEL	TWIN Front Hook	TWIN Front Hook E-Z Grip® Handle	FULL Front Hook
280A14	225-1001	225-1026	225-1003
280B14	225-1001	225-1026	225-1003
35-280	225-1010	225-1052	
35-40	225-1010	225-1052	
35-50	225-1010	225-1052	
380A14	225-1001	225-1026	225-1003
380B14	225-1001	225-1026	225-1003
40-18	225-1002		225-1027††
40A14	225-1001	225-1026	225-1003
40B14	225-1001	225-1026	225-1003
50-18	225-1002		225-1027††
50A14	225-1001	225-1026	225-1003
50B14	225-1001	225-1026	225-1003
G280A14SS	225-1001	225-1026	225-1003
G280B14	225-1001	225-1026	225-1003
G280B14SS	225-1001	225-1026	225-1003

FRYER MODEL	TWIN Left Hook	TWIN Right Hook
1031	225-1037	225-1036
36EIS11BL	225-1037	225-1036
36ES11	225-1037	225-1036
36ES11SF	225-1037	225-1036
36ES11SFBL	225-1037	225-1036
36ET11	225-1037	225-1036
36ET11SF	225-1037	225-1036
680-31F	225-1037	225-1036
680-31FBL	225-1037	225-1036
680-31SF	225-1037	225-1036
680-31SFBL	225-1037	225-1036
780-31SF	225-1037	225-1036
780-31SFB6	225-1037	225-1036
780-31SFBL	225-1037	225-1036
E24-31F	225-1037	225-1036
E24-31SF	225-1037	225-1036

HENNY PENNY®

FRYER MODEL	TWIN Rear Hook	TRIPLE Rear Hook Vinyl-coated Handle
OE301	227-1054	
OG301	227-1054	227-1053
OG303	227-1054	
OFG321		227-1053

Note: Inspect condition of basket wires before each use. Immediately replace basket when wires appear bent, missing, or damaged.

* No. 225-1001 can be used in place of this basket

** Nos. 169-1054 and 225-1084 can be used in place of this basket

*** Standard vinyl-coated handle

† No. 225-1026 can be used in place of this basket

†† This basket has 2 side handles

HOBART® (GE)

FRYER MODEL	TWIN Left Hook	TWIN Right Hook
AK20	225-1009	225-1008
AK40	225-1007	225-1006
AK42	225-1007	225-1006
AK45	225-1007	225-1006
AK401	225-1007	225-1006
AK421	225-1007	225-1006
CK20	225-1009	225-1008
CK40	225-1007	225-1006
CK42	225-1007	225-1006
CK45	225-1007	225-1006
CK201	225-1009	225-1008
CK401	225-1007	225-1006
CK421	225-1007	225-1006
DK20	225-1009	225-1008
DK40	225-1007	225-1006
DK42	225-1007	225-1006
DK45	225-1007	225-1006
DK401	225-1007	225-1006
DK421	225-1007	225-1006
HK3	225-1005*	225-1004*
HK7	225-1007	225-1006
HK8	225-1009	225-1008
HK31	225-1005*	225-1004*

IMPERIAL®

FRYER MODEL	TWIN Front Hook	TWIN Front Hook E-Z Grip® Handle
IF-25		225-1026
IFP-40		225-1026
IFS-40		225-1026
IFS-75	225-1002	

KEATING

FRYER MODEL	TWIN Front Hook	TWIN Front Hook Vinyl-coated Handle	FULL Front Hook	TRIPLE Front Hook	TRIPLE Front Hook Vinyl-coated Handle
10 x 11	225-1000	225-1082**			
14	225-1060	225-1061**	225-1003	225-1041†	169-1054†
18	225-1002				
C-11		169-1049			
C-14				225-1041†	169-1054†
24AA		225-1081***			
24BB		225-1081***			
24TS		225-1081***			

PITCO®

FRYER MODEL	TWIN Front Hook	TWIN Front Hook E-Z Grip® Handle
6 series	225-1000	225-1082
6D	225-1000	225-1082
6DI	225-1000	225-1082
7 series	225-1060	225-1061
7DI	225-1060	225-1061
12 series	225-1000	225-1082
12C	225-1000	225-1082
12CS	225-1000	225-1082
12D	225-1000	225-1082
12D2	225-1000	225-1082
12DI	225-1000	225-1082
12DIS	225-1000	225-1082

PITCO® (continued)

FRYER MODEL	TWIN Front Hook	TWIN Front Hook E-Z Grip® Handle	FULL Front Hook	TRIPLE Front Hook
12S	225-1000	225-1082		
126D	225-1000	225-1082		
14 series	225-1060	225-1061	225-1003	
14-2	225-1060	225-1061	225-1003	
14-2UFM	225-1060	225-1061	225-1003	
14-R2	225-1060	225-1061	225-1003	
147	225-1060	225-1061	225-1003	
147UFM	225-1060	225-1061	225-1003	
14B	225-1060	225-1061	225-1003	
14BA	225-1060	225-1061	225-1003	
14BS	225-1060	225-1061	225-1003	
14BDI	225-1060	225-1061	225-1003	
14DI	225-1060	225-1061	225-1003	
14R	225-1060	225-1061	225-1003	
14RDI	225-1060	225-1061	225-1003	
14RS	225-1060	225-1061	225-1003	
18 series	225-1002		225-1027††	225-1054
18-2	225-1002		225-1027††	225-1054
18-2UFM	225-1002		225-1027††	225-1054
18DI	225-1002		225-1027††	225-1054
18S	225-1002		225-1027††	225-1054
35C+	225-1060			
E7	225-1060	225-1061		
E7B	225-1060	225-1061		
E7BS	225-1060	225-1061		
E7S	225-1060	225-1061		
E12	225-1000	225-1082		
E12A	225-1000	225-1082		
E12A2	225-1000	225-1082		
E12S	225-1000	225-1082		
E14	225-1060	225-1061	225-1003	
E14-2	225-1060	225-1061	225-1003	
E14-3UFM	225-1060	225-1061	225-1003	
E14BS	225-1060	225-1061	225-1003	
E14S	225-1060	225-1061	225-1003	
E14X	225-1060	225-1061	225-1003	
E14XS	225-1060	225-1061	225-1003	
E147	225-1060	225-1061	225-1003	
E147UFA	225-1060	225-1061	225-1003	
E147UFM	225-1060	225-1061	225-1003	
E14B	225-1060	225-1061	225-1003	
E14B-2	225-1060	225-1061	225-1003	
E18	225-1002		225-1027††	225-1054
E18-2	225-1002		225-1027††	225-1054
E18B	225-1002		225-1027††	225-1054
E18BS	225-1002		225-1027††	225-1054
E18S	225-1002		225-1027††	225-1054
HE7	225-1060	225-1061		
HE14	225-1060	225-1061	225-1003	
HE147	225-1060	225-1061	225-1003	
HE18	225-1002		225-1027††	225-1054
HE18S	225-1002		225-1027††	225-1054
PM14	225-1060	225-1061	225-1003	
PM14S	225-1060	225-1061	225-1003	
PR14	225-1060	225-1061	225-1003	
PR14S	225-1060	225-1061	225-1003	
RPB14	225-1060	225-1061	225-1003	
RPB14B	225-1060	225-1061	225-1003	
RPB14BS	225-1060	225-1061	225-1003	
RPB14S	225-1060	225-1061	225-1003	
SG14	225-1060	225-1061		175-1164**

* This basket also has a front hook

** E-Z Grip® vinyl-coated handle

*** This basket has a front assist handle

† No. 225-1084 can be used in place of this basket

†† This basket has 2 side handles

SOUTHBEND

FRYER MODEL	TWIN Front Hook	TWIN Front Hook E-Z Grip® Handle	FULL Front Hook
14-32	225-1060	225-1061	225-1003
14-36	225-1060	225-1061	225-1003
14-42	225-1060	225-1061	225-1003
18-36	225-1002		225-1053*
18-42	225-1002		225-1053*

STAR

FRYER MODEL	FULL Left Hook	FULL Right Hook
110HL	225-1051	225-1050
115D	225-1051	225-1050
116D	225-1051	225-1050
116DL	225-1051	225-1050
216	225-1051	225-1050
515	225-1051	225-1050
515E	225-1051	225-1050
530T	225-1051	225-1050
530TE	225-1051	225-1050
EM14***	225-1010	225-1052
EM14DL***	225-1010	225-1052
EM40***	225-1010	225-1052
EM40DL***	225-1010	225-1052
M14	225-1010	225-1052
M14D	225-1010	225-1052
M14DL	225-1010	225-1052
M43	225-1010	225-1052

TOASTMASTER®

FRYER MODEL	TWIN Left Hook	TWIN Right Hook
1404E	225-1037	225-1036
1405	225-1037	225-1036
1405E	225-1037	225-1036
1407	225-1018**	225-1019**
1412L	225-1018**	225-1019**
1414B	225-1037	225-1036
1427	225-1018**	225-1019**
1435	225-1037	225-1036
1445	225-1037	225-1036
1454	225-1037	225-1036
1455	225-1037	225-1036
1465	225-1037	225-1036
1467	225-1018**	225-1019**
1475	225-1037	225-1036
1485	225-1037	225-1036
1495	225-1037	225-1036
1497	225-1018**	225-1019**
14A2	225-1018**	225-1019**
14A3	225-1018**	225-1019**
14A4	225-1018**	225-1019**
14A5	225-1018**	225-1019**
14C4	225-1037	225-1036
FR29 Series	225-1037	225-1036

VULCAN-HART®

FRYER MODEL	TWIN Front Hook	TWIN Front Hook E-Z Grip® Handle	FULL Front Hook
17891E	225-1060	225-1061	225-1003
17891G	225-1060	225-1061	225-1003
17892E	225-1042		225-1027†
17892G	225-1042		225-1027†
7494E	225-1060	225-1061	225-1003
7495E	225-1002		225-1027†
7594G	225-1060	225-1061	225-1003
7595G	225-1002		225-1027†
7891E	225-1060	225-1061	225-1003
7891G	225-1060	225-1061	225-1003
7892E	225-1042		225-1027†
7892G	225-1042		225-1027†
EF3	225-1060		
EF4	225-1060		
EF5	225-1060		
GR35	225-1060		
GR45	225-1060		
HEF22	225-1060	225-1061	225-1003
HEF22F	225-1060	225-1061	225-1003
SPE1	225-1060	225-1061	225-1003
SPE101	225-1060	225-1061	225-1003
SPE11	225-1060	225-1061	225-1003
SPE111	225-1060	225-1061	225-1003
SPE12	225-1060	225-1061	225-1003
SPE2	225-1060	225-1061	225-1003
SPE202	225-1060	225-1061	225-1003
SPE22	225-1060	225-1061	225-1003
SPE222	225-1060	225-1061	225-1003
SPG12	225-1060	225-1061	225-1003
SPG2	225-1060	225-1061	225-1003
TK35	225-1060	225-1061	
TK45	225-1060		
TK65		225-1066	

FRYER MODEL	TWIN Left Hook	TWIN Right Hook
VF1	225-1037	225-1036
VTMF1	225-1037	225-1036

* This basket has an assist handle

** This basket also has a front hook

*** For models with serial nos. 145021 and after

† This basket has 2 side handles

WELLS®

FRYER MODEL	TWIN Front Hook	FULL Front Hook
----------------	--------------------	--------------------

F49	225-1034	225-1033
F55	225-1034	225-1033
F58	225-1034	225-1033
F67	225-1034	225-1033
F68	225-1034	225-1033
F85	225-1034	225-1033
F88	225-1034	225-1033
F99	225-1031 *	
F101	225-1031 *	
F104	225-1031 *	
F104S4	225-1031 *	
F104S5	225-1031 *	
F106	225-1031 *	
F108	225-1031 *	
F556	225-1034	225-1033
F586	225-1034	225-1033
F676	225-1034	225-1033
F686	225-1034	225-1033
F856	225-1034	225-1033
F886	225-1034	225-1033
F996	225-1031 *	
F1016	225-1031 *	
F1086	225-1031 *	
F1200	225-1032	
F1725	225-1032	
F2000	225-1032	
FB101	225-1031 *	
FB108	225-1031 *	
FB2000	225-1032	
FC101	225-1031 *	
FGH50	225-1032	
FGH508	225-1032	
FGS40	225-1032	
FGS40-2	225-1032	
FNW49	225-1034	225-1033
FNW58	225-1034	225-1033
FS1200	225-1032	
FS1725	225-1032	
RCB12	225-1031 *	
RCB101	225-1031 *	

WOLF®

FRYER MODEL	TWIN Front Hook	TWIN Front Hook E-Z Grip® Handle
WTF35	225-1060	225-1061
WTF42	225-1001	225-1026

* Includes left and right handles and rear stand-off support

STANDARD BASKET SIZE CHART

ITEM No.	LENGTH	WIDTH	HEIGHT	HOOK LOCATION
225-1011	8¾"	4⅛"	4½"	Front
225-1018	9¾"	4⅞"	5⅝"	Left/front
225-1019	9¾"	4⅞"	5⅝"	Right/front
225-1034	10"	4"	5¼"	Front
225-1033	10"	7¾"	5¼"	Front
225-1050	10"	8¾"	5¼"	Right/front
225-1051	10"	8¾"	5¼"	Left/front
225-1014	10¾"	6¾"	5"	Left
225-1015	10¾"	6¾"	5"	Right
225-1055	11"	4½"	5"	Front
225-1000	11"	5⅝"	4⅞"	Front
225-1012	11¼"	4"	4"	Left
225-1013	11¼"	4"	4"	Right
225-1062	12⅛"	6⅝"	5⅞"	Front
225-1035	12⅛"	6¼"	5⅝"	Front
225-1001	12⅞"	6½"	5⅝"	Front
225-1003	13"	12¼"	5⅝"	Front
225-1037	13¼"	5⅝"	5⅝"	Left
225-1036	13¼"	5⅝"	5⅝"	Right
225-1041	13¼"	4¼"	5½"	Front
225-1010	13¼"	5¾"	5¾"	Front
227-1054	13¼"	6¼"	6"	Rear
225-1060	13¼"	6½"	6"	Front
225-1032	14¾"	5⅞"	5¼"	Front
225-1042	16"	8½"	6"	Front
225-1053**	16¾"	17½"	6"	Front
225-1027***	16¾"	17½"	6"	Front
225-1054	17⅞"	5¾"	6"	Front
225-1002	17⅞"	8¼"	6"	Front

E-Z GRIP® FRYER BASKETS

ITEM No.	LENGTH	WIDTH	HEIGHT	HOOK LOCATION	HANDLE COLOR
225-1082	11"	5⅝"	4¼"	Front	Teal
225-1063	12⅞"	6⅝"	5⅞"	Front	Teal
225-1026	12⅞"	6½"	5⅝"	Front	Teal
225-1073	13"	12¼"	5¼"	Front	Teal
225-1084	13¼"	4¼"	5½"	Front	Teal
175-1164	13¼"	4½"	5½"	Front	Blue
225-1052	13¼"	5¾"	5¾"	Front	Teal
225-1061	13¼"	6½"	6"	Front	Teal
225-1066	13¼"	9¼"	6"	Front	Teal
225-1072	17⅞"	8⅝"	6"	Front	Teal

E-Z GRIP® PLUS FRYER BASKETS

ITEM No.	LENGTH	WIDTH	HEIGHT	HOOK LOCATION	HANDLE COLOR
225-1069	12⅞"	6½"	5⅝"	Front	Teal
225-1070	13¼"	6½"	6"	Front	Teal
225-1071	17⅞"	5¾"	6"	Front	Teal

Note: Inspect condition of basket wires before each use. Immediately replace basket when wires appear bent, missing, or damaged.