# **Tear-N-Dry Essence** TOUCHLESS TOWEL DISPENSERS INSTRUCTIONS

## **MOUNTING INSTRUCTIONS (Dispenser must be mounted level)**

The user is responsible for the proper installation and use of this dispenser.

### **Equipment needed:**

Measuring tape Level Screwdriver Eye protection Pencil Drill and drill bit Assemble appropriate fasteners (screws, bolts, anchors, washers, etc.) for mounting.

- Determine position on wall/surface with unit open. Through the holes at the back of the unit, use pencil to mark the spots where the drilling will be necessary. Be sure unit is level before marking holes. WARNING: Proper function of this dispenser requires level mounting. Try to mark spots as close as possible to the outer edges.
- 2. Drill the marked spots on the wall/surface with appropriate sized drill bit suitable for the wall material and fasteners used.
- 3. Complete the installation. Be sure to use fasteners (and anchors) in all mounting holes that are appropriate for the wall/surface to which the dispenser will be mounted. The installation should be done with a flat washer between the head of the fastener and the inside back of the dispenser.

## **BATTERY LOADING:**

The Tear-N-Dry Essence is powered by 4 D-cell alkaline batteries. Take care to load batteries in correct orientation as shown on the battery compartment inside door. After inserting batteries wait 5 seconds before closing cover. If the batteries are loaded incorrectly, the Tear-N-Dry Essence will not function. A flashing red indicator light indicates that batteries need to be replaced. **AWARNING: Do not use rechargeable or NiCad batteries as these may cause damage to your dispenser or personal injury.** 

Take care to load batteries in correct orientation, with positive end of battery towards the left as you are facing the dispenser. (Tenga cuidado al instalar las baterías, oriéntelas con el lado positivo hacia su izquierda cuando este de frente al dispensador).	
+ ( Rechargeable NhCad	
Note: If batteries are loaded incorrectly, the unit will not function. (Nota: Si las baterías son instaladas incorrectamente, el unidad no funcionará.)	

## PAPER LOADING:

- Step I Open cover and load paper onto hubs.
- Step 2 Pull down and drape so that paper is hanging off the back of the roll.
- **Step 3** Pinch paper by rolling between two rollers.
- **Step 4** Close cover. Dispenser will feed the first sheet and is ready for use.

#### **USING THE DISPENSER**

After loading paper and supplying power, simply close the dispenser cover. A towel will be dispensed, and the Tear-N-Dry Essence is now ready for use.

### PROBLEMS

Typical problems can be corrected by opening and closing the cover. If that fails to resolve the problem, try removing and then reinserting the batteries. If that fails, try replacing with new batteries.

## **Other Accessories Available**



X100916\* Classic Replacement Cover X100916\* Couvercle de Rechange Classique X100916\* Tapa de Reemplazo (Classic)

\* Please specify color: (TBK) Black Pearl, (TBL) Artic Blue, or (WH) White



NI6 Replacement Key NI6 Clef De Remplacement NI6 Llave de Reemplazo



XT102194\* Oceans Replacement Cover XT102194\* Couvercle de Rechange Oceans XT102194\* Tapa de Reemplazo (Oceans) \* Please specify color: (TBK) Black Pearl or (TBL) Artic Blue



T1438 Replacement Lock Fingers T1438 Doigts de serrure T1438 Dedos de la Cerradura de Reemplazo

# Matching Oceans<sup>®</sup> and Classic Dispensers Available













San Jamar 555 Koopman Lane Elkhorn, Wisconsin 53121 USA T: +1.262.723.6133 F: +1.262.723.4204 info@sanjamar.com www.sanjamar.com Canada 15252 32nd Avenue Suite 309 Surrey, BC V3S 0R7 CANADA T: +1.262.723.6133 F: +1.262.723.4204 canada@sanjamar.com

#### Europe

Schoorstraat 26a, bus I 2220 Heist op-den Berg BELGIUM T: +32 I 5 22 8I 40 F: +32 I 5 22 8I 48 emea@sanjamar.com

#### México

Av. Paseo de la Reforma No. 350 - 10 Col. Juarez Deleg. Cuauhtemoc, CP 06600 MEXICO, D.F. T: +52 (55) 3626 0772 mexico@sanjamar.com



© Copyright San Jamar, Inc. 2016