

SERV-WARE[™]

Stainless Steel Backsplash

**UC27-BS • UC36-BS • UC48-BS
UC60-BS • UC72-BS**


Under Counter Refrigerator/Freezer

Assembly & Installation Guide


For questions, contact the
Service department at:
sw-service@servware.com
or call 800-768-5953

ASSEMBLY PARTS LIST

1 Backsplash (1 pc)



2 Screws (4 pcs)



ASSEMBLY TOOL LIST

B Phillips Head Screw Driver




Backsplash Compatibility Chart

Backsplash	SWP Under Counter Model No.
UC27-BS	UCR-27-HC UCF-27-HC
UC36-BS	UCR-36-HC UCF-36-HC
UC48-BS	UCR-48-HC UCF-48-HC
UC60-BS	UCR-60-HC UCF-60-HC
UC72-BS	UCR-72-HC UCF-72-HC


STEP 1

Locate the two unused prefabricated threaded screw holes on the top left and top right back corners of the under counter unit.




STEP 2

Make the holes on two sides of backsplash align with screw holes on sides of top. Then attach with screws.




STEP 3

Using screw driver finish tightening all four back splash kit screws making sure not to strip screws from over tightening.



1

FINAL ASSEMBLY



Front of Unit