

AUTOMATIC SLICER

Cleaning & Sanitizing Procedures



Supplies

1. Personal Protective Equipment (PPE): rubber gloves, safety gloves, protective eye glasses, protective apron
2. Properly diluted/labeled spray bottle of **dish soap** (mid-day cleaning)
3. Properly diluted/labeled spray bottle of **foaming chlorinated cleaner & degreaser** (end-of-day cleaning)
4. Properly diluted/labeled bucket of dish soap solution
5. Properly diluted/labeled spray bottle of no rinse sanitizer
6. Plastic bucket of fresh, clean rinse water
7. Scrub brush
8. White scrub pad
9. Disposable cloths

Precautions

1. Put on **rubber gloves** and **safety goggles** prior to handling chemicals/solutions
2. Put on **safety gloves** prior to handling/touching saw blades, etc.
3. Turn off slicer and disconnect from power source prior to cleaning and sanitizing
4. Disassemble slicer according to manufacturer's instructions
5. Handle sharp parts safely during disassembly, moving, and storage
6. When cleaning around sharp parts, use scrub brush only
7. Cover electrical outlets/controls with plastic to protect them from water

Procedures

1. Remove loose food and soil from slicer
2. For mid-day cleaning: spray slicer with **dish soap solution**
3. For end-of-day cleaning: spray slicer with **foaming chlorinated cleaner & degreaser**
4. Clean sharp areas with scrub brush and remaining areas with scrub pad and/or brush
5. Pay special attention to areas where food may have been lodged or trapped
6. Rinse with fresh clean water
7. Sanitize by spraying with no rinse sanitizer
8. Allow to air dry
9. Clean any disassembled parts in bucket of fresh dish soap or immerse in dish sink, wearing safety gloves and using scrub brush
10. Rinse in fresh clean water
11. Sanitize by immersing in sanitizing sink or by spraying with no rinse sanitizer
12. Allow to air dry
13. Reassemble according to manufacturer's instructions
14. Check that all surfaces are clean and free of food, grease, etc.
15. Assure that all safety guards are in place before leaving slicer



Blue Velvet
NL316-G4



N601 +
NL644-G4

